

Halo

Model# S8/N

Stand + Net

INSTRUCTIONS



P.O. Box 487, Emu Plains NSW 2750
Service No: 02 4728 8090

IMPORTANT: Before assembling,
please read instructions carefully.
Incorrect assembly may make unsafe.

Issue: C

OPERATING INSTRUCTIONS

Important - Retain for future reference, read all instructions carefully before use

Step 1: Assemble pole clamp kit (Fig 1).

Step 2: Insert pole (A) into Pole (B) and then into (C). Fix with Screw (Fig 2).

Step 3: Slide pole clamp kit (D) over 19mm straight tube (A,B,C). This may require placing large diameter (22mm) end of white plastic pole clamp just over end of tube A,B,C and tapping on the floor so that kit (D) is completely on tube A,B,C (See Fig 2.)

Step 4: Fix bottom "U" Feet (F) to straight pole with self tapping screw supplied (See Fig 3).

Step 5: Fix top hoop section (E) to straight pole with self tapping screw supplied. (See Fig 3).

Step 6: To place in position in relation to the cot, place the feet (F) under the side or end of the cot. Slide kit (D) down straight pole, with "L" bracket facing down till it is firmly over the top of cot side or end. (The metal "L" bracket can be adjusted to the thickness of the cot side or end by moving the metal flat nut on the thread in or out.

FIGURE 1




FIGURE 2







FIGURE 3



FITTING THE NET TO THE HALO STAND




1. Locate the rod pocket and feed metal rod through.



2. The rod pocket has a ribbon tie coming out from it. Do not untie the ceiling ribbon tie.



3. Feeding Halo rod pocket onto metal bar.



4. Feed netting on Halo until you come to the end of rod pocket. Space netting out as you go.



5. Locate ribbon ties at each end of pocket



6. Tie a ribbon to hold into place.



7. It should now look like the illustration above.



8. Place the Halo stand under your cot and drape the netting around it as shown above.

Infasecure Warranty Details

Infasecure Pty Ltd warrants this product for twelve months from the date of purchase against failure due to manufacturing faults or faulty materials. Misuse, accidental damages, normal wear and tear or defect are not covered by this warranty. When used for commercial use the period is limited to six months. "Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure."

Refer to website for details: www.infasecure.com.au